

# WES 237A: Introduction to Embedded System Design (Winter 2026)

## Lab 5: Inter-Integrated Circuit (I2C) Communication

Due: 3/1/2026 11:59pm

In order to report and reflect on your WES 237A labs, please complete this Post-Lab report by the end of the weekend by submitting the following 2 parts:

- Upload your lab 5 report composed by a single PDF that includes your in-lab answers to the bolded questions in the Google Doc Lab and your Jupyter Notebook code. You could either scan your written copy, or simply type your answer in this Google Doc. **However, please make sure your responses are readable.**
- Answer two short essay-like questions on your Lab experience.

All responses should be submitted to Canvas. Please also be sure to push your code to your git repo as well.

- Connect the PMOD\_AD2 peripheral to PMODA.
- Download the [iic\\_example.ipynb](#)
- Go through the notebook and answer the following questions. The following resources may be helpful
  - [https://pynq.readthedocs.io/en/v2.6.1/pynq\\_libraries/pynqmb\\_reference.html](https://pynq.readthedocs.io/en/v2.6.1/pynq_libraries/pynqmb_reference.html)
  - [https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991\\_7995\\_7999\\_9.pdf](https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991_7995_7999_9.pdf)
  - [https://pynq.readthedocs.io/en/v2.1/pynq\\_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod](https://pynq.readthedocs.io/en/v2.1/pynq_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod)

- **What command opens a new I2C device in the MicroblazeLibrary? What are the two parameters to this command?**

device = liba.i2c\_open(3, 2)

The two parameters are the PMOD pins that connect to SCL and SCA, respectively

- **What does 0x28 refer to in the following line?**
- device.write(0x28, buf, 1)

0x28 indicates the device I2C address that you want to write to

- **Why do we write and then read when using the Microblaze Library, compared to just reading in the PMOD Library?**

The write indicates which input channel we want to read from. Once we establish which input channel, we can then send a read command the device will be able to read from the correct channel.

- **What does this code snippet mean? return ((buf[0] & 0x0F) << 8) | buf[1]**

It takes the contents of buf[0] (the first byte that gets returned from the device) and shifts it over by 8, then ORs the contents of that with the contents of the second buffer.

Because the device can only return one byte at a time and the output is more than 8 bits, we need to OR the two buffer contents together and shift them accordingly to get the intended output.

- **What is the difference between writing to the device when using the Microblaze Library and directly on the Microblaze?**

The library defines the device as an object, where each object has its own read and write functions to interact with the device.

When writing directly on the Microblaze, we use a more general write function, where the arguments define the device you want to write to along with the other parameters.

# Using PYNQ library for PMOD\_ADC

This just uses the built in Pmod\_ADC library to read the value on the PMOD\_AD2 peripheral.

```
In [1]: from pynq.overlay.base import BaseOverlay  
from pynq.lib import Pmod_ADC  
base = BaseOverlay("base.bit")
```

```
In [2]: adc = Pmod_ADC(base.PMODA)
```

Read the raw value and the 12 bit values from channel 1.

Refer to docs:

[https://pynq.readthedocs.io/en/v2.1/pynq\\_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod](https://pynq.readthedocs.io/en/v2.1/pynq_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod) ([https://pynq.readthedocs.io/en/v2.1/pynq\\_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod](https://pynq.readthedocs.io/en/v2.1/pynq_package/pynq.lib/pynq.lib.pmod.html#pynq-lib-pmod))

```
In [3]: adc.read_raw(ch1=1, ch2=0, ch3=0)
```

```
Out[3]: [4095]
```

```
In [4]: adc.read(ch1=1, ch2=0, ch3=0)
```

```
Out[4]: [1.9995]
```

# Using MicroblazeLibrary

Here we're going down a level and using the microblaze library to write I2C commands directly to the PMOD\_AD2 peripheral

Use the documentation on the PMOD\_AD2 to answer lab questions

```
In [5]: from pynq.overlay.base import BaseOverlay  
from pynq.lib import MicroblazeLibrary  
base = BaseOverlay("base.bit")
```

```
In [6]: liba = MicroblazeLibrary(base.PMODA, ['i2c'])
```

In [7]: `dir(lib) # list the available commands for the lib object`

Out[7]: `['__class__', '__delattr__', '__dict__', '__dir__', '__doc__', '__eq__', '__format__', '__ge__', '__getattribute__', '__gt__', '__hash__', '__init__', '__init_subclass__', '__le__', '__lt__', '__module__', '__ne__', '__new__', '__reduce__', '__reduce_ex__', '__repr__', '__setattr__', '__sizeof__', '__str__', '__subclasshook__', '__weakref__', '_build_constants', '_build_functions', '_mb', '_populate_typedefs', '_rpc_stream', 'active_functions', 'i2c_close', 'i2c_get_num_devices', 'i2c_open', 'i2c_open_device', 'i2c_read', 'i2c_write', 'release', 'reset', 'visitor']`

In the cell below, open a new i2c device. Check the resources for the i2c\_open parameters

In [9]: `device = lib.i2c_open(3, 2)`

In [10]: `dir(device) # list the commands for the device class`

Out[10]: `['__class__', '__delattr__', '__dict__', '__dir__', '__doc__', '__eq__', '__format__', '__ge__', '__getattribute__', '__gt__', '__hash__', '__index__', '__init__', '__init_subclass__', '__int__', '__le__', '__lt__', '__module__', '__ne__', '__new__', '__reduce__', '__reduce_ex__', '__repr__', '__setattr__', '__sizeof__', '__str__', '__subclasshook__', '__weakref__', '_call_func', '_file', '_val', 'close', 'read', 'write']`

Below we write a command to the I2C channel and then read from the I2C channel. Change the buf[0] value to select different channels. See the AD spec sheet Configuration Register.

[https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991\\_7995\\_7999.pdf](https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991_7995_7999.pdf) ([https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991\\_7995\\_7999.pdf](https://www.analog.com/media/en/technical-documentation/data-sheets/AD7991_7995_7999.pdf))

Changing the number of channels to read from will require a 2 byte read for each channel!

In [15]: `buf = bytearray(2)
buf[0] = int('00010000', 2)
device.write(0x28, buf, 1)
device.read(0x28, buf, 2)
print(format(int(((buf[0] << 8) | buf[1])), '#018b'))`

0b0000011010011110

Compare the binary output given by `((buf[0]<<8) | buf[1])` to the AD7991 spec sheet. You can select the data only using the following command

```
In [16]: result_12bit = (((buf[0] & 0x0F) << 8) | buf[1])
```

## Using MicroBlaze

```
In [17]: base = BaseOverlay("base.bit")
```

```
In [20]: %%microblaze base.PMODA

#include "i2c.h"

int read_adc(){
    i2c_device = i2c_open(3, 2);
    unsigned char buf[2];
    buf[0] = 0b00010000;
    i2c_write(device, 0x28, buf, 1);
    i2c_read(device, 0x28, buf, 2);
    return ((buf[0] & 0x0F) << 8) | buf[1];
}
```

```
In [42]: read_adc()
```

```
Out[42]: 52
```

```
In [ ]:
```